



Consommable pour machine laser

TRUMPF / 2009





"Оборудование Интернейшенел"


Тел. +7 (495) 413-0095

Факс +7 (495) 413-9580


www.obint.ru
info@obint.ru

Ref.-No.	Order-No.	Description
Consumables suitable for Trumpf Trumatic L2530-L3030-L3050-L4030-6000L L6030-L2503E-L3003E-L4003E-TC600L All nozzles in boxes of 10		
Standard copper nozzles		
0124561	HG 10.150	Nozzle Ø 0,8 mm.....
0124562	HG 10.151	Nozzle Ø 1,0 mm.....
0966809	HG 10.148	Nozzle Ø 1,2 mm.....
0237497	HG 10.152	Nozzle Ø 1,4 mm with step.....
237497-S	HG 10.159	Nozzle Ø 1,4 mm with straight taper.....
237500	HG 10.153	Nozzle Ø 1,5 mm.....
0237501	HG 10.154	Nozzle Ø 1,7 mm.....
1253211	HG 10.155	Nozzle Ø 2,0 mm.....
0126933	HG 10.158	Nozzle Ø 2,3 mm.....
	HG 10.156	Nozzle Ø 2,5 mm.....
0942742	HG 10.149	Nozzle Ø 2,7 mm.....
237504	HG 10.157	Nozzle Ø 3,0 mm.....
		
Nozzles with hard chromium plating		
0352280	HG 10.150/C	Nozzle Ø 0,8 mm Hard chromium plating.....
0352281	HG 10.151/C	Nozzle Ø 1,0 mm Hard chromium plating.....
0352282	HG 10.148/C	Nozzle Ø 1,2 mm Hard chromium plating.....
0352283	HG 10.152/C	Nozzle Ø 1,4 mm Hard chromium plating.....
0352284	HG 10.154/C	Nozzle Ø 1,7 mm Hard chromium plating.....
1253212	HG 10.155/C	Nozzle Ø 2,0 mm Hard chromium plating.....
0352285	HG 10.158/C	Nozzle Ø 2,3 mm Hard chromium plating.....
0352286	HG 10.149/C	Nozzle Ø 2,7 mm Hard chromium plating.....
		
Long copper nozzles		
<i>Shortens the distance to the old cutting edge and reduces the danger of collision (up-turned parts) !!</i>		
1277773	HG 10.130	Nozzle Ø 0,8 mm.....
1277771	HG 10.131	Nozzle Ø 1,0 mm.....
1277774	HG 10.132	Nozzle Ø 1,2 mm.....
1277776	HG 10.133	Nozzle Ø 1,4 mm.....
1277779	HG 10.134	Nozzle Ø 1,7 mm.....
1277780	HG 10.135	Nozzle Ø 2,0 mm.....
1277781	HG 10.136	Nozzle Ø 2,3 mm.....
1277782	HG 10.137	Nozzle Ø 2,7 mm.....
		
Long nozzles with hard chromium plating		
<i>Shortens the distance to the old cutting edge and reduces the danger of collision (up-turned parts) !!</i>		
	HG 10.130/C	Nozzle Ø 0,8 mm Hard chromium plating.....
	HG 10.131/C	Nozzle Ø 1,0 mm Hard chromium plating.....
	HG 10.132/C	Nozzle Ø 1,2 mm Hard chromium plating.....
	HG 10.133/C	Nozzle Ø 1,4 mm Hard chromium plating.....
	HG 10.134/C	Nozzle Ø 1,7 mm Hard chromium plating.....
	HG 10.135/C	Nozzle Ø 2,0 mm Hard chromium plating.....
	HG 10.136/C	Nozzle Ø 2,3 mm Hard chromium plating.....
	HG 10.137/C	Nozzle Ø 2,7 mm Hard chromium plating.....
		

Ref.-No.	Order-No.	Description	
Consumables suitable for Trumpf Trumatic L2530-L3030-L3050-L4030-6000L L6030-L2503E-L3003E-L4003E-TC600L			
234485	HG 10.163	 Break-away-bar.....	
0353188	HG 10.107	 Ceramic nozzle holder (Lasermatic)..... old Ref 0258809	
0260432	HG 10.109	 Ceramic nozzle holder DIAS III.....	
216066	HG 10.165	 Locking nut.....	
0225286	HG 10.160	 Teflon - Cover white (Lasermatic).....	
254496	HG 10.161	 Teflon - Cover white.....	
256153 0955826	HG 10.162 HG 10.162/1	 Teflon - Cover DIAS III white..... Teflon - Cover DIAS III black.....	
Consumables suitable for Trumpf Laser L1003/L2503/L3003/L4003			
0353188	HG 10.107	 Ceramic nozzle holder (Lasermatic) old Ref 0353188 Due to patent protection not to be exported to the Federal Republic of Germany !!	
216066	HG 10.165	 Locking nut.....	
215780 087658 088894 217867	HG 10.100 HG 10.101 HG 10.102 HG 10.104	 Nozzle Ø 0,8 mm..... Nozzle Ø 1,0 mm..... Nozzle Ø 1,4 mm high pressure..... Nozzle Ø 1,7 mm high pressure.....	All nozzles packed in boxes of 10
088893 221781 235592	HG 10.103 HG 10.105 HG 10.108	 Nozzle Ø 1,5 mm..... Nozzle Ø 2,0 mm..... Nozzle Ø 3,0 mm.....	
216065	HG 10.112	 Teflon - Cover.....	

Ref.-No.	Order-No.	Description	
Consumables suitable for Trumpf Laser TLC 105			
913965	HG 10.007		Locking nut.....
All nozzles packed in boxes of 10			
Standard copper nozzles			
0212334	HG 10.010		Nozzle Ø 1,0 mm.....
	HG 10.025		Nozzle Ø 1,0 mm HD..... M.P.S Design.....
0216199	HG 10.011		Nozzle Ø 1,4 mm HD.....
0225213	HG 10.012		Nozzle Ø 1,7 mm HD.....
0126156	HG 10.028		Nozzle Ø 2,3 mm HD.....
237364	HG 10.019		"Shower" - nozzle Ø 1,0 mm.....
226939	HG 10.013		Nozzle Ø 1,0 mm.....
	HG 10.026		Nozzle Ø 1,0 mm HD..... M.P.S Design.....
226940	HG 10.014		Nozzle Ø 1,4 mm HD.....
227144	HG 10.015		Nozzle Ø 1,7 mm HD.....
	HG 10.029		Nozzle Ø 2,3 mm HD.....
0135320	HG 10.016		Nozzle Ø 1,0 mm.....
0135318	HG 10.017		Nozzle Ø 1,4 mm HD.....
0126157	HG 10.018		Nozzle Ø 1,7 mm HD.....
	HG 10.030		Nozzle Ø 2,3 mm HD.....
	HG 10.008		"Teach" Nozzle Ø 0,25 mm rough edged.....
	HG 10.225		Nozzle Ø 1,0 mm rough edged.....
	HG 10.226		Nozzle Ø 1,2 mm rough edged.....
	HG 10.220		Nozzle Ø 1,4 mm rough edged.....
	HG 10.221		Nozzle Ø 1,7 mm rough edged.....
Nozzles with hard chromium plating			
0212334	HG 10.010/C		Nozzle Ø 1,0 mm Hard chromium plating.....
	HG 10.025/C		Nozzle Ø 1,0 mm HD Hard chromium plating.....
0216199	HG 10.011/C		Nozzle Ø 1,4 mm HD Hard chromium plating.....
0225213	HG 10.012/C		Nozzle Ø 1,7 mm HD Hard chromium plating.....
0126156	HG 10.028/C		Nozzle Ø 2,3 mm HD Hard chromium plating.....
226939	HG 10.013/C		Nozzle Ø 1,0 mm Hard chromium plating.....
	HG 10.026/C		Nozzle Ø 1,0 mm HD Hard chromium plating.....
226940	HG 10.014/C		Nozzle Ø 1,4 mm HD Hard chromium plating.....
227144	HG 10.015/C		Nozzle Ø 1,7 mm HD Hard chromium plating.....
	HG 10.029/C		Nozzle Ø 2,3 mm HD Hard chromium plating.....
0135320	HG 10.016/C		Nozzle Ø 1,0 mm Hard chromium plating.....
0135318	HG 10.017/C		Nozzle Ø 1,4 mm HD Hard chromium plating.....
0126157	HG 10.018/C		Nozzle Ø 1,7 mm HD Hard chromium plating.....
	HG 10.030/C		Nozzle Ø 2,3 mm HD Hard chromium plating.....
	HG 10.225/C		Nozzle Ø 1,0 mm rough edged Hard chrom.plating
	HG 10.226/C		Nozzle Ø 1,2 mm rough edged Hard chrom.plating
	HG 10.220/C		Nozzle Ø 1,4 mm rough edged Hard chrom.plating
	HG 10.221/C		Nozzle Ø 1,7 mm rough edged Hard chrom.plating

Page D

Ref.- No.	Order-No.	Description	
913965	HG 10.007	 Locking nut.....	
Consumable suitable for Trumpf Laser TLC 1005			
All nozzles packed in boxes of 10			
Standard copper nozzles			
0958206	HG 10.006		"Teach" Nozzle Ø 0,25 mm.....
0913799	HG 10.020		Nozzle Ø 0,8 mm HD.....
0913800	HG 10.021		Nozzle Ø 1,0 mm HD.....
0913801	HG 10.022		Nozzle Ø 1,4 mm HD.....
0937988	HG 10.023		Nozzle Ø 1,7 mm HD.....
0937989	HG 10.024		Nozzle Ø 2,3 mm HD.....
Nozzles with hard chromium plating			
0913799	HG 10.020/C		Nozzle Ø 0,8 mm HD Hard chromium plating.....
0913800	HG 10.021/C		Nozzle Ø 1,0 mm HD Hard chromium plating.....
0913801	HG 10.022/C		Nozzle Ø 1,4 mm HD Hard chromium plating.....
0937988	HG 10.023/C		Nozzle Ø 1,7 mm HD Hard chromium plating.....
0937989	HG 10.024/C		Nozzle Ø 2,3 mm HD Hard chromium plating.....
Consumable suitable for Trumpf Laser 240 / 260			
202952	HG 10.002		Nozzle Ø 0,8 mm.....
218969	HG 10.003		Nozzle Ø 1,0 mm.....
209402	HG 10.000		Nozzle Ø 1,4 mm HD.....
211533	HG 10.001		Nozzle Ø 1,7 mm HD.....


Page E

Ref.-No.	Order-No.	Description	
		Air - Filters suitable for Trumpf	
	HG 10.187	Air-Filter for cooling aggregate Size: 1520 x 755 x 8mm, Package with 25 pieces	
	HG 10.188	Air-Filter for cooling aggregate Size: 1670 x 660 x 8mm, Package with 25 pieces	
	HG 10.189	Air-Filter for cooling aggregate Size: 2420 x 560 x 8mm, Package with 25 pieces	
	HG 10.190	Air-Filter for cooling aggregate Size: 1200 x 700 x 8mm, Package with 25 pieces	
	HG 10.191	Air-Filter for cooling aggregate Size: 990 x 890 x 8mm, Package with 25 pieces	
		M.P.S	
		CO₂ - Laser - Lens	
		Suitable for Trumpf / TruLaser	
1383925	HG 10.125/H	ZnSe-Meniscus Lens 8,10" High Pressure Lens, Ø 40,0 mm Effective Focal Length: 155,0 mm Edge Thickness: 7,6 mm AR/AR for 10,6µm (Absorption <0.20%)	
		M.P.S Polish Polish for laseroptics, 100ml	
	HG 10.174	Lens cleaning paper from Tiffen® From the producer of Kodak® paper (<i>no longer available!!</i>) Sheet size: ca. 70 x 115 mm, Package containing: 50 sheets	
	HG 10.173		
	HG 15.099	Cleaning holder (Teflon) for lenses (to use on both sides)	
		 with Ø 38.10mm	
		 with Ø 50.80mm	

Ref.-No.	Order-No.	Description	
		CO₂ - Laser - Lenses suitable for Trumpf	
0346104	HG 10.166/H	ZnSe-Meniscus Lens 3,75" High Pressure Lens (25 bar), Ø 38,1 mm Effective Focal Length: 95,3 mm Edge Thickness: 7,4 mm AR/AR for 10,6µm (Absorption <0.20%)	
088114	HG 10.167/H	ZnSe-Meniscus Lens 5,00" High Pressure Lens (25 bar), Ø 38,1 mm Effective Focal Length: 127,0 mm Edge Thickness: 7,4 mm AR/AR for 10,6µm (Absorption <0.20%)	
097517	HG 10.168/H	ZnSe-Meniscus Lens 7,50" High Pressure Lens (25 bar), Ø 38,1 mm Effective Focal Length: 190,5 mm Edge Thickness: 7,4 mm AR/AR for 10,6µm (Absorption <0.20%)	
0141972	HG 10.169/H	ZnSe-Meniscus Lens 9,00" High Pressure Lens (25 bar), Ø 38,1 mm Effective Focal Length: 225,0 mm Edge Thickness: 7,4 mm AR/AR for 10,6µm (Absorption <0.20%)	
0350163	HG 10.179/H	ZnSe-Meniscus Lens 10,00" High Pressure Lens (25 bar), Ø 38,1 mm Effective Focal Length: 254,0 mm Edge Thickness: 7,4 mm AR/AR for 10,6µm (Absorption <0.20%)	
		For a laserpower above 4kW, we do recommend lenses with the special M.P.S Ultra Low coating for the following reasons. These lenses do offer a lower absorption (<0.15%). The results of the lower heat absorption are less tensions and optical distortions. Furthermore the focal length is more stable. Also in case of a slightly dirty lens you can still profit from these advantages. Since the lenses are not black, the function of the lens sensing system is not interfered (red aiming beam compatible). The degree of dirtiness can be determined by the system. M.P.S Ultra Low lenses are appropriately marked on the edge.	
088114	HG 10.167/HU	ZnSe-Meniscus Lens 5,00" High Pressure Lens (25 bar), Ø 38,1 mm Effective Focal Length: 127,0 mm Edge Thickness: 7,4 mm M.P.S Ultra Low AR/AR for 10,6µm (Absorption <0.15%)	
097517	HG 10.168/HU	ZnSe-Meniscus Lens 7,50" High Pressure Lens (25 bar), Ø 38,1 mm Effective Focal Length: 190,5 mm Edge Thickness: 7,4 mm M.P.S Ultra Low AR/AR for 10,6µm (Absorption <0.15%)	
0141972	HG 10.169/HU	ZnSe-Meniscus Lens 9,00" High Pressure Lens (25 bar), Ø 38,1 mm Effective Focal Length: 225,0 mm Edge Thickness: 7,4 mm M.P.S Ultra Low AR/AR for 10,6µm (Absorption <0.15%)	
0350163	HG 10.179/HU	ZnSe-Meniscus Lens 10,00" High Pressure Lens (25 bar), Ø 38,1 mm Effective Focal Length: 254,0 mm Edge Thickness: 7,4 mm M.P.S Ultra Low AR/AR for 10,6µm (Absorption <0.15%)	

Ref.-No.	Order-No.	Description	
		M.P.S Accessories for cleaning CO₂ - Laser - Lenses	
	HG 10.174	M.P.S Polish Polish for laseroptics, 100ml	
	HG 10.173	Lens cleaning paper from Tiffen® From the producer of Kodak® paper (<i>no longer available!!</i>) Sheet size: ca. 70 x 115 mm, Package containing: 50 sheets	
	HG 15.136	Latex gloves (package containing: 100 pcs)	
	HG 15.138	EM-080 general-purpose cleaning concentrate Bottle of 500 ml	
	HG 15.099	Cleaning holder (Teflon) for lenses (<i>to use on both sides</i>)  with Ø 38.10mm  with Ø 50.80mm	

Dirt & Strain Viewer for Lenses and Cleaning Set



Picture 1




It is easily visible, that this lens is dirty.

Picture 2



Here are two small pieces of backscatter in the very center of the lens.

Picture 3



Lens was overheated (stress). This cannot be seen with the naked eye. This problem is mainly occurring with lasers with a power of 4, 5, 6 or 7kW.

Here we do recommend our **M.P.S Ultra Low®** - lenses with very low absorption values.

Picture 4



The bright spots at the edge of the lens show, that the lens was mounted too tight in the holder. The reason is, that the holder is dirty or was screwed too tight. Because the lens consists of soft material, it is strained, so that you have problems finding the focussing point and it is stressed very easily. You can see the stress in the middle of the lens (shadow - cross). All this is not visible with the naked eye. Because you could not see the cause without the dirt & strain viewer, every new lens would have been also damaged when built in.

C'est aussi

